Paper Cutter

User Manual SKU #2215614

SAVE THESE INSTRUCTIONS

FEATURES

- 12in (30.48cm) Self-Sharpening Blade
- Cutting Capacity Up to 16 Sheets (Varies with Paper Thickness)
- Alignment Grid with ½-Inch Grid Lines
- Ruler Markings in Inches and Centimeters
- Guardrail
- Safety Latch
- Storage Drawer

SAFETY PRECAUTIONS

All safety and operating instructions should be read before product is operated and adhered to while operating.

- Adult Use Only — Keep away from children and pets.
- Do not cut any material other than paper with this product.
- Never place fingers, hands, or other body parts below blade.
- Before each use, always inspect product for damages. Do not use if damaged.

ASSEMBLY

To assemble blade lever, ensure blade arm is in locked position, then slide handle onto blade arm until it snaps into place.

BASIC USE

1. Place on flat, stable surface and unlock blade lever's safety latch. **NOTE:** Once unlocked, blade lever will rise up.
2. Align paper face up on base. Use built-in grid or ruler to measure exact cut line. **NOTE:** Do not stack more than 16 sheets of paper at one time.
3. Hold paper down to prevent shifting.
4. Ensure fingers and hands are clear of blade, then pull blade lever down in one swift, even motion.
5. When finished, return blade lever to lowered position and lock safety latch.

SAFETY LATCH

- To unlock blade lever, rotate safety latch away from peg. Once unlocked, blade lever will rise up.
- To lock blade lever, pull blade lever down and away from trimmer, slide in toward trimmer, and rotate safety latch onto peg.

©2026 Hobby Lobby • Oklahoma City, OK 73179
www.hobbylobby.com • Made in China

⚠ CAUTION:
ADULT USE ONLY-Product contains functional sharp objects.

Scanned + Archived By: FindMyManual.org