


AQV002PM AQUASCENE AQUARIUM KIT

GETTING STARTED

See **IMPORTANT SAFETY INSTRUCTIONS** section before operating this unit. Completely assemble aquarium before plugging in. For household use only.

- 1) Assemble all parts from package carefully and check to make sure you have all the parts. If you are missing any parts please call our toll free number and we will send you whatever you are missing.
- 2) The area you are going to place the aquarium should not get any direct sunlight and make sure the surface you place it on cannot be damaged from water.
- 3) Rinse the tank with warm water only-**NEVER USE SOAP OR CLEANER OF ANY KIND TO CLEAN THE TANK.**
- 4) Insert riser tube all the way into the socket provided in the filter plate.
- 5) Lower the assembled filter plate assembly into the tank with the riser tube pointing up.
- 6) Add gravel and decorations as desired (purchased separately). You should use a minimum of 1 pound of aquarium gravel in this aquarium. Be sure to cover the filter plate well to keep it in position and allow it to function properly.
- 7) Connect the air stone to one end of the airline tubing and insert the air stone into the top of the riser tube and position it all the way to the bottom of the riser tube.
- 8) Connect the other end of the airline tubing to the air pump and be sure to leave a drip loop in it as illustrated.
- 9) Fill the tank with water to approximately 1/2" above the riser tube.
- 10) Place the light hood onto the top of the tank and make sure it is seated flush onto the tanks rim. **THE CLEAR LENS MUST BE IN PLACE BEFORE OPERATING THIS UNIT!**
- 11) Install the light socket assembly by lining up the notches in the light hood. Push forward until flange of the light socket assembly is flush with the light hood. Twist clockwise until the light socket assembly is securely attached to the light hood. Take care to grasp the body of the light socket assembly and not the switch when twisting.
- 12) **NEVER SUBMERGE THE HOOD IN WATER** Plug light hood into a standard 110 volt wall socket.
- 13) Form a drip loop as illustrated to the right and plug the air pump into a standard 110 volt wall socket.
- 14) **BEFORE ADDING FISH** the water should be checked for it's suitability to accept whatever type of fish you will be adding. Please check the "Aquarium Setup Tips" insert for when to add fish and how many.

ASSEMBLY INSTRUCTIONS





TO REPLACE THE BULB

NEVER REPLACE IF THE HOOD OR SOCKET ASSEMBLY IS WET

- 1) Turn off light and let cool for at least 5 minutes.
- 2) Unplug light and remove hood from tank
- 3) Twist socket assembly counter clockwise and remove from the light hood.
- 4) Unscrew the old bulb and screw in the replacement bulb making sure to **USE ONLY MAXIMUM 7 WATT (TYPE C-7) BULB.**
- 5) Install the light socket assembly by lining up the notches in the light hood. Push forward until the flange of the light socket assembly is flush with the light hood. Twist clockwise until the light socket assembly is securely attached to the light hood. Take care to grasp the body of the light socket assembly and not the switch when twisting.
- 6) Place the light hood onto the top of the tank and make sure it is seated flush onto the tank's rim. **THE CLEAR LENS MUST BE IN PLACE BEFORE OPERATING THIS UNIT!**
- 7) Plug light hood back into a standard 110 volt wall socket.

Note: The clear lens can be removed from the light hood for cleaning using a small flat bladed tool or screw driver by carefully prying it out.



Lens must be in place during operation

Grasp body of socket during assembly and when switching on and off

Turn socket assembly clockwise to install, counterclockwise to remove

IF ANY PARTS ARE MISSING OR DAMAGED, PLEASE CALL:

800-545-1344

Dist. by/par:
Pacific Coast Distributing, Inc.
19601 North 27th Ave
Phoenix, AZ USA 85207

Note: Light hood is designed to be used with tank provided with dimensions shown on hood above and a 5/16" recess.

MANUFACTURER LIMITED WARRANTY

The MANUFACTURER warrants this aquarium product to be free from defects in material and workmanship under normal use and service and according to the provisions as specified in the accompanying assembly and operating instructions, for a period of 90 days from date of purchase.

This warranty does not cover and the MANUFACTURER is not liable for the cost of repair or replacement of parts which have been subject to misuse, negligence, accident, improper installation, damage during shipment or handling, normal deterioration due to wear and exposure or defects caused by unauthorized parts or modification.

UNDER NO CIRCUMSTANCES WILL THE MANUFACTURER BE LIABLE FOR ACCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF PROPERTY OR EQUIPMENT

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you the legal rights, which vary from state to state.

Procedure for Warranty Repairs or Replacement

If warranty service is necessary, the original purchaser must send the part postage paid with the description of the defect, proof of purchase, to the following address:

KOLLERCRAFT
PO BOX 718
Fenton, MO 63026