



Single-hole buttons

Here's something that no one could have dreamed of before Buttoneer. All it takes is one fastener – and **pop!** A single-hole button is on. Use round-head fasteners when you use single-hole buttons for shirts, children's clothes, etc.

A sample of these buttons is included with this kit. You can purchase extra single-hole buttons where you bought your Buttoneer kit.



HOLE-SIZER

Tips

CARE. Your Buttoneer attachment needs no maintenance. But the needle should **never** be abused. To prevent damage to the needle, make it a practice to **keep the protective cover on the needle at all times when the attachment is not in actual use.**

JAMMING. If a fastener ever twists and gets stuck in the mechanism, simply pull it out.

FINE FABRICS. To provide reinforcement for sheer, loosely woven fabrics, make a small washer out of some heavier fabric such as felt and use it to back up the fine fabric where you are attaching the button.

BUTTON SIZING. The holes in some conventional buttons may be too small to permit passage of the needle. To enlarge the holes, gently twist the small key-shaped metal hole-sizer into them until the hole-sizer turns freely.

HIDDEN STITCH. On garments with double layers of fabric, such as a coat, you can separate the layers and attach buttons through the outer layer alone. The fastener is then hidden by the under layer of fabric.

CLEANING & WASHING. Buttoneer fasteners are made of tough synthetic filament that is not affected by dry cleaning fluids, soaps, or detergents. But extreme heat will melt them. So avoid contact with a hot iron.

Other uses

There's a lot more to your Buttoneer attachment than just attaching buttons. For the creative homemaker, it's a handy decorating device **and** the answer to hundreds of household repair problems.

DECORATE . . . Attach sequins or applique to hats, garments, etc. • Decorate luggage • Add trim, lace or braid to garments • Decorate pillows • "Dress up" garment bags • "Brighten up" potholders • Add buttons, emblems, etc. to blazers, sweatshirts • Decorate shower curtains and shower caps • Add ribbons, collars, cuffs • Decorate dolls and toys • Make holiday decorations • Decorate packages • Attach name tags • Pleat curtains and add hooks to draperies.

REPAIR . . . Make strap and zipper repairs • Fix fallen hems, ripped seams • Repair auto upholstery • Attach mittens to snow suits • Repair linings in garments • Tack pant cuffs • Repair cushions • Repair curtains and draperies • Fix torn pockets.

Dennison Manufacturing Company will repair any Buttoneer® which has not been subjected to misuse, negligence or accident. Enclose \$1.00 to cover cost of repair, return postage, and handling. Mail the button attachment, **ONLY**, with the needle protector in place, postage prepaid to Dennison Manufacturing Company, Buttoneer® Attacher Service, P.O. Box 20, Princeton, N.J. 08540 U.S.A.

enjoy your

Buttoneer®2

instant button attachment and all the extra time you'll save by using it. Now you'll do hundreds of sewing, mending and decorating jobs – in a fraction of the time it used to take!


Everything you need is right in the kit.

As you'll see, your new Buttoneer attachment is fun and easier than ever to use. The more you use it, the more valuable it will become. Use it often!




Scanned + Archived
By:
FindMyManual.org






Here's how to operate Buttoneer® 2

1. Insert a clip of fasteners into the slot behind the needle. The long strip to which the fasteners are attached feeds into the very bottom of this opening.
2. Advance the first fastener into position right behind the needle by turning the white wheel. (Do this every time you get ready to use a fastener.)



3. Put the button in place, and insert the needle through the hole in the button and through the fabric to which the button is to be attached.
4. Hold the button and the fabric firmly against the tip of the Buttoneer 2 attachment and squeeze the handle. That's all there is to it!




How to choose the right fastener

You'll notice that there are two types of fasteners in the kit – some with round heads and some with "T" heads. And there are two sizes of each type.

ROUND HEADS. These fasteners can be used on regular buttons – i.e., buttons with holes in them.


"T" HEADS. These fasteners are for use on shank buttons and for special effects, such as the sewn effect.

Choose the **size** of fastener according to the size of the button, the size of the holes in the button and the thickness of the fabric. As a guide, **always use a fastener that's long enough to allow a little "play" – to make for ease in buttoning.**



How to attach shank buttons

1. Load your Buttoneer with shank fasteners. Insert the needle from the underside of the fabric, through the shank on the button. Squeeze the handle.
2. Slip the loose end of the fastener into the groove at the point of the needle.
3. Insert the needle back through the fabric and squeeze the handle again.
4. This is how it should look.



How to get a "sewn" effect

1. Proceed in much the same way as you do to attach a shank button. Load your Buttoneer attachment with shank fasteners. Insert the needle through a hole in the button and through the fabric. Squeeze the handle.
2. Slip the loose end of the fastener into the groove at the point of the needle.
3. Insert the needle through another hole in the button and through the fabric. Squeeze the handle again.
4. Your buttons can look like this. Or like this. Or like this.