Sku Numbers: 346-0646

Patriot LIGHTING®

Scanned + Archived By: FindMyManual.org

12FT LED ST38 STRING LIGHT

Model Number: 0106-0038

Questions, problems, missing parts?
Before returning to your retailer, call our customer service at
1-844-255-9692 Monday – Friday 8:00 a.m. – 5:00 p.m. CST

PACKAGE CONTENTS





PART	DESCRIPTION	QUANTITY
A	12Ft String Light with 12 Attached ST38 LED Lamps	1
B	Spare LED Filament	1
C	Spare ST38 Lamp Lens	1

Note: Hardware not shown to actual size.

Patriot Lighting® is a registered trademark of Menard, Inc. All Rights Reserved.

⚠ SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

WARNING: When using outdoor use portable lighting products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

a) Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuits or outlet to be used for the outdoor use flexible lighting product. Receptacles are available that have built-in GFCI protection for this measure of safety.

b) Only use outdoor extension cords such as type SEW, SEOW, SEOOW, SOW, SOOW, STW, STOW, STOOW, SJEW, SJEOW, SJEOOW, SJW, SJOW, SJOOW, SJTW, SJTOW, or SJTOOW. This designation is marked on the wire of the extension cord.

- Read and follow all instructions that are on the product or provided with the product.
- This product operates at 120V, 60Hz 0.07A 8.4w per string
- This seasonal use product is not intended for permanent installation or use.
- Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Unplug the product when leaving the vicinity of the product or when left unattended.
- This is an electric product and is not a toy! To avoid risk of fire, burns, personal injury, and electric shock, it should not be played with or placed where small children can reach it.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper, or any material not part of the product when in use.
- This product is equipped with screw type lamps. Do not use excessive force when installing lamps.
- Do not operate this product with lamps missing from sockets. Missing lamps should be replaced promptly.
- This product is rated for damp locations only. Do not expose directly to water.
- Risk of fire: This product does not contain lamp shunts which allow the product to operate if one lamp burns out. Replace lamps only with the spare lamps provided with this product.
- DO NOT EXCEED THE MAXIMUM EXTENSION LENGTH IN FEET PERMITTED BY THE MARKING. The maximum wattage for this string light which is 432 watts or 50 units. When adding additional extension pieces, use only Patriot® 346-0646 12FT LED ST38 String Light.

SAVE THESE INSTRUCTIONS

PREPARATION

Before beginning assembly, installation, or operation of product, make sure all parts are present. Compare parts with package and hardware contents lists on page 1. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.

Tools Required for Assembly (not included): Phillips Screwdriver, Safety Glasses, Ladder, Supporting hardware (eyebolts or brackets)

Estimated assembly time: 20 minutes

INSTALLATION INSTRUCTIONS

WARNING

- Disconnect power at the source prior to beginning installation or servicing product.
- Be careful not to damage or cut the wire insulation (covering) during fixture installation. Do not permit power cord or wires to contact any surface having a sharp edge. To do so may damage or cut the wire insulation, which could cause serious injury or death from electric shock.
- String light sockets must be suspended so that lamps are facing downwards. DO NOT mount the light string with sockets facing upward. Lamps should hang freely with at least 3 inches of space from nearest object.

1. Carefully remove all the parts from the packaging, and gently lay them out on a smooth workspace. Remove the packing material and uncoil the string light (A). Be careful not to cut or nick the string nor damage the pre-attached lamps.



2. Ensure each lamp is securely fastened within each socket by gently turning clockwise. Do not over-turn.



3. Securely attach string light (A) to a support structure using appropriate supporting hardware (eyebolts, hooks, brackets, etc. not included). The maximum unsupported distance is 20 feet. Use an appropriately rated cable support system for spans over 20 feet (not included).



4. Plug the beginning of the string light (A) into an appropriate power outlet. Check to ensure each lamp (B) lights up.



5. If using the string light outdoors, be sure to use a rain-tight receptacle cover. Product is rated for damp location use only. Do not expose directly to water.

EXTENDING THE SERIES

1. Ensure that all string lights (A) are unplugged before adding additional string light (A) segments to the series.



2. Connect two string lights together by pushing the male and female end connections together, ensuring a tight connection. Ensure the last string in the series has its end cap attached.



NOTE: Maximum number of adjacent units that can be inter-connected is 50.

CARE AND MAINTENANCE

- When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown and break off easily. Keep the tree holder filled with water.
- If the product is placed on a tree, the tree should be well secured and stable.
- Before using or reusing, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the lamp-holders or enclosures, loose connections, or exposed copper wire.
- When storing the product, carefully remove the product from wherever it is placed, including trees, branches, or bushes in order to avoid any undue strain or stress on the product conductors, connections, and wires.
- When not in use, store neatly in a cool, dry location protected from sunlight.

TROUBLESHOOTING

1) The light does not come on at all:
   a) Make sure the wall switch and circuit breaker are on.
2) One of the lamps has burned out.
   a) Disconnect power to the string light. Remove effected lamp by gently gripping lamp lens and turning in a counter-clockwise direction. Gently pull out the LED filament piece, then replace with the spare LED filament piece included. Push in until fully seated. Only use spare part provided with this string. Replace the lamp lens by inserting over LED filament, then gently turn the lamp in a clockwise direction until fully seated.



If unable to fix any of the above issues, please consult a certified electrician.

FIVE-YEAR LIMITED WARRANTY

If, during normal use, this PATRIOT LIGHTING® lighting fixture breaks or fails due to a defect in material and workmanship within five (5) years from the date of original purchase, simply bring this lighting fixture with your original sales receipt back to your nearest MENARDS® retail store. At its discretion, PATRIOT LIGHTING® agrees to have the product or any defective part(s) repaired or replaced with the same or similar PATRIOT LIGHTING® product free of charge, within the stated warranty period, when returned by the original purchaser with original sales receipt. This warranty; (1) excludes expendable parts including but not limited to light bulbs; (2) does not cover damage that has resulted from abuse or misuse; and (3) does not cover any losses, labor, injuries to persons/ property or costs. This warranty does give you specific legal rights and you may have other rights, which vary from state to state.